



PLATE W

STEERING

Plate No.	Part No.	Description	No. per Unit	Remarks
W1	307756	STEERING WHEEL	1	
	308229	STEERING WHEEL	1	U.S.A. only. Fitted from Comm. No. FDU31254 and future
W2	105438	NUT, steering wheel	1	
W3	140755	STEERING COLUMN, UPPER, ASSEMBLY	1	
	141625	STEERING COLUMN, UPPER, ASSEMBLY (Locking)	1	
W4	140549	CLIP, cancelling, trafficator	1	
W5	209688	STEERING COLUMN, LOWER	1	
W6	122718	CAP, end, steering column cowl	1	
W7	122719	WASHER, bearing	1	
W8	122669	CLAMP, steering column	1	
W9	125782	PLATE, locating — Clamp to steering column	1	
W10	125781	SCREW, locating — Clamp to steering column	1	
W11	JN2110	NUT, jam — Clamp to steering column	1	
W12	HB0710	BOLT — Clamp to steering column	2	
W13	WL0207	WASHER, lock — Clamp to steering column	2	
	149698	TUBE, distance, cardboard, steering column	1	L.H.S. only
	142140	FLEXIBLE JOINT ASSEMBLY	1	
W14	110960	PLATE, flexible joint	1	
W15	108977	BUSH, rubber, adaptor plate	8	
W16	142139	ADAPTOR, flexible joint	2	
W17	108976	BOLT, plate and bushes to adaptor	4	
W18	502136	WASHER, plain, on bolt	4	
W19	110461	STRIP, conductor, on bolt	1	
	502148	WIRE, locking bolt	4	
W20	HB0810	BOLT — Adaptor to column and unit	2	
W21	TN3208	NUT, nyloc — Adaptor to column and unit	2	
	305932	†RACK AND PINION ASSEMBLY — R.H.S.	1	
	305931	†RACK AND PINION ASSEMBLY — L.H.S.	1	
	515291	†RACK AND PINION ASSEMBLY — R.H.S. (Fitted with grease nipples)	1	} Scandinavian countries and to special order only
	515290	†RACK AND PINION ASSEMBLY — L.H.S. (Fitted with grease nipples)	1	
W22	Not Serviced	RACK AND PINION BODY	1	
	145108	PLUG, nylon, fitted in rack and pinion body	1	
	128002	BUSH, rack tube	1	
	128020	COVER, end	1	
W23	208058	RACK	1	
W24	127997	BUSH, pinion, lower	1	
W25	128000	WASHER, thrust, lower	1	
W26	134689	PINION — R.H.S.	1	
	134688	PINION — L.H.S.	1	
W27	127999	WASHER, thrust, upper	1	

Note:—Items marked thus † are available on our Factory Exchange Unit Scheme

STEERING

Plate No.	Part No.	Description	No. per Unit	Remarks
RACK AND PINION ASSEMBLY (continued)				
W28	127998	BUSH, pinion, upper	1	
	120941	SHIM	A/R	
W29	128021	"O" RING	1	
W30	128001	PLUG, end	1	
	128008	PIN	1	
W31	509537	CIRCLIP	1	
W32	120946	PLUNGER	1	
	143952	WASHER, packing, plunger	1	
W33	126765	SPRING	1	
W34	120959	SHIM, .002"	A/R	
W34	120949	SHIM, .004"	A/R	
W34	132055	SHIM, .010"	A/R	
W35	132053	CAP, screwed	1	
W36	133103	PLUG, grease	1	
	129961	INNER BALL JOINT ASSEMBLY	2	
W37	128024	HOUSING, ball	2	
W38	128023	PIN, ball	2	
W39	120955	SOCKET, ball	2	
W40	120957	WASHER, tab	2	
	130031	SHIM, .002"	A/R	
	130032	SHIM, .010"	A/R	
W41	129963	SLEEVE, adaptor	2	
W42	120953	SPRING	2	
W43	142795	LOCKNUT	2	
W44	128004	BELLOWS, driver's side	1	
W45	120948	BELLOWS, passenger's side	1	
W46	CS4009	CLIP, bellows	2	
	CS4020	CLIP, bellows, passenger's side	1	
W47	512781	WIRE, binding bellows, driver's side	1	
W48	136600	BALL JOINT ASSEMBLY, TIE ROD END	2	
W49	512420	GAITER assembly	2	
W50	TN3209	NUT, nyloc	2	
	146728	BALL JOINT ASSEMBLY, TIE ROD END (Fitted with grease nipples)	2	} Scandinavian countries and to special order
	500098	NIPPLE, grease	2	
	WF0541	WASHER, fibre, grease nipple	2	
	104775	SEAL, oil, ball joint assembly	2	
	TN3209	NUT, nyloc	2	
	WP0045	WASHER, plain	2	
W51	128022	LOCKNUT, ball joint attachment	2	
W52	139386	MOUNTING RUBBER, RACK AND PINION BODY	2	
W53	136885	CLAMP assembly — Rack and pinion body to frame	2	
W54	133875	PLATE, reinforcement — Rack and pinion body to frame	2	
W55	YN2908	NUT, nyloc — Rack and pinion body to frame	4	
W56	WP0008	WASHER, plain — Rack and pinion body to frame	4	

Note:—Items marked thus † are available on our Factory Exchange Unit Scheme